

ADV10PF and ADV10PFIR File Loading Instructions



The **ADV10PF & ADV10PFIR** supports MPEG2 and AVI video file types, as well as JPEG images with MP3 audio. Maximum file size: 496MB.

To load your file(s) into the internal flash memory in the ADV10PF/ADV10PFIR, your file name must start with the prefix "AE" in upper case letters, such as AE001.AVI, AE002.AVI, etc.

1. Load your file onto a USB Flash Drive.
2. With the power to the ADV10PF turned OFF, insert the USB drive into the USB port on the ADV10PF/ADV10PFIR.
3. Turn the power ON to the ADV10PF/ADV10PFIR. Your file will be automatically downloaded into the internal flash memory of the ADV10PF/ADV10PFIR, overwriting any files previously stored in the internal flash memory.
4. Turn the ADV10PF/ADV10PFIR power OFF and remove the USB drive.
5. Turn the ADV10PF/ADV10PFIR power ON and your file(s) will begin to play.

NOTE 1: The USB port on the ADV10PF/ADV10PFIR is used to load files into the internal flash memory in the ADV10PF/ADV10PFIR. Files cannot be played directly from a USB flash drive.

NOTE 2: Files can be played directly from an SD card inserted into the SD card slot on the ADV10PF/ADV10PFIR, but cannot be loaded into the internal flash memory in the ADV10PF/ADV10PFIR from the SD card slot.

Playing Sequence

- Video files only: Plays the files in sequence.
- Audio files only: Plays the files in sequence.
- Image files only: Plays the files in sequence.
- Video & Image files: First plays video files, then image files, then repeats.
- Video & Audio files: First plays video files, then plays audio files, then repeats.
- Image & Audio files: Plays the image and audio files simultaneously.
- Image, Audio & Video files: First plays video files, then plays image and audio files simultaneously, then repeats.